

RICOMAN®

CTC WALL CONTROL (RE22) OPERATING INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION AND LEAVE
A COPY WITH THE END USER FOR FUTURE REFERENCE



PRODUCT INFORMATION

Product Name: Wall Mounted Control (RE22)

Associated Product: RICOMAN CTC Panel (R101107)*

Control Range: 20 Metres (good signal clearance)

Quantity Limit: Up to 6 series, each series with up to 99 panels

Available Luminaire Series Names: 1, 2, 11, 12, 21, 22

Control Functions: On/Off, colour temperature and dimming level

Important: Control should only be used as a secondary control switch. Resync will require all luminaires to be switched off from the primary control switch.

THE VARIOUS CONTROL FUNCTIONS

- POWER ON
- POWER OFF
- INPUT NUMBER 1
- INPUT NUMBER 2
- DIMMING +
- DIMMING -
- COLOUR TEMPERATURE -
- COLOUR TEMPERATURE +
- SELECT ALL

To control a particular series of luminaire(s):
press the series number first, followed by the
desired function button.

To select all luminaires: press "ALL" first, and
then press the desired function button.

STEPS TO ASSIGN A SERIES NUMBER TO THE LUMINAIRE(S)

1. Power on the luminaire/luminaires through the primary switch
2. Within three seconds assign and choose one unique number from the "Available Series Name" list (see PRODUCT INFORMATION above)
3. Confirm by pressing the buttons on the round ring in this particular order: black (top), white (bottom), left dark circle (left) and right dark circle (right)
4. The luminaire/luminaires will then flash and switch off to confirm signal is received.
5. Power off the luminaire/luminaires within 10 seconds of seeing it flashing. This confirms that the setting of series number is valid.

If the luminaire/luminaires is not switched off within the 10 seconds time frame, the luminaire/luminaires will turn on again. This confirms that the last attempt to set is invalid.

NIGHT MODE

When the luminaire/luminaires are in power off mode, press the "white sun" to activate the luminaire/luminaires to night mode (3% brightness level).

**Note: Any single luminaire can be linked with 1 of RE22 (wall mounted control) and/or RE23 (remote control).*